

DST Setting / Module : 5554

※ [If you are connected to a mobile phone, please switch from the G-SHOCK Connected app.](#)

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down ③ for two seconds.



In the Timekeeping Mode, hold down ① until "SET" stops flashing. The hands will move at 12 o'clock etc.



Press ③ **twice**.
"Hour" flashes.



Press ② or ④ to change the hour.

4.



Press **A** to return to the Timekeeping Mode.

<Timekeeping Mode Screen>



The hands also change to the time set in above number 3.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>