

Manual abstract:

These features help you reduce the time needed to place or receive calls on your mobile device. · Position your device within easy reach. Be able to access your wireless device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, let your voice mail answer it for you. · Let the person you are speaking with know you are driving. Suspend calls in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and heavy traffic can be hazardous. · Do not take notes or look up phone numbers. Jotting down a "to do" list or flipping through your address book takes attention away from your primary responsibility of driving safely. · Dial sensibly and assess the traffic.

Place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call, dial only a few numbers, check the road and your mirrors, then continue. · Do not engage in stressful or emotional conversations that may be distracting. Make people you are talking with aware you are driving and suspend conversations that have the potential to divert your attention from the road.

· Some of the contents in this manual may differ from your phone · Third party services may be terminated or interrupted at any time, and Samsung makes no representation or warranty that any content or service will remain available for any period of time. · This product includes certain free/open source software.

The exact terms of the licenses, disclaimers, acknowledgements and notices are available on the Samsung's website opensource.samsung.com depending on the software of the phone or your service provider. Caution: Follow all safety warnings and regulations when using your device in restricted areas Turn off your device where prohibited Comply with all regulations that restrict the use of a mobile device in a particular area. Do not use your device near other electronic devices Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices. Do not use your device near a pacemaker · Avoid using your device within a 15 cm range of a pacemaker if possible, as your device can interfere with the pacemaker. · If you must use your device, keep at least 15 cm away from the pacemaker. www.samsung.com Printed in Korea GH68-35696A English (EU). 09/2011.

Rev. 1.0 · Use your device to call for help. Dial a local emergency number in the case of fire, traffic accident, or medical emergencies. · Use your device to help others in emergencies. If you see an auto accident, a crime in progress, or a serious emergency where lives are in danger, call a local emergency number. · Call roadside assistance or a special, non-emergency assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or another special, nonemergency number. Do not store your device with such metal objects as coins, keys and necklaces · Your device may become deformed or malfunction. · If the battery terminals are in contact with metal objects, it may cause a fire.

Do not store your device near magnetic fields · Your device may malfunction or the battery may discharge from exposure to magnetic fields. · Magnetic stripe cards, including credit cards, phone cards, passbooks, and boarding passes, may be damaged by magnetic fields. · Do not use carrying cases or accessories with magnetic closures or allow your device to come in contact with magnetic fields for extended periods of time. Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers · The battery may leak. · Your device may overheat and cause a fire.

Do not drop your device or cause impacts to your device · The screen of your device may be damaged. · If bent or deformed, your device may be damaged or parts may malfunction. If your device has a camera flash or light, do not use a flash close to the eyes of people or pets Using a flash close to the eyes may cause temporary loss of vision or damage to the eyes..



[Your user manual](#)
[SAMSUNG GT-C3520](#)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>