





## Alienware Hangar18 Quick Start Guide



HDTV must be HDCP compliant



Blu-ray Disc™ 1080p HD Connection



**NOTE:** The video outputs shaded above (HDMI, VGA and Component) will not be functional when using the HDMI 1080p graphics card.




You can playback your Blu-ray Disc™ DVD's from the Vista Media Center main menu.


OPTION 1 - Connect to your HDTV via 1080p HDMI cable



# Alienware Hangar18 Quick Start Guide



## OPTION 2 - Connect to your HDTV via 720p HDMI cable





2


## OPTION 3 - Connect to your HDTV via Component cable





# Alienware Hangar18 Quick Start Guide



720p HD Connection




## OPTION 4 - Connect to your HDTV via VGA cable




## Connect to 5.1 speakers 3

# Alienware Hangar18 Quick Start Guide



Connect power cord and turn POWER switch to ON position



4 Connect USB receiver for TV remote

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>